

REVISION HISTORY						
REV	DESCRIPTION	DATE	APPROVED			
С	DCN 35051	04/07	STW			
D	DCN 37413	03/10	PJS			
E	DCN 42006	1/16	STW			

## STEP 1: TRIM CABLE TO DIMENSION SHOWN. TIN EXPOSED AREA OF CENTER CONDUCTOR.

## STEP 2: PLACE CONNECTOR CONTACT OVER CABLE CENTER CONDUCTOR. USE A SPACER OR SHIM TO MAINTAIN THE COMPENSATION GAP. SOFT SOLDER CONNECTOR CONTACT TO CABLE CENTER CONDUCTOR. REMOVE SPACER OR SHIM.

## STEP 3: INSERT CABLE/CONTACT ASSEMBLY INTO CONNECTOR ASSEMBLY AS SHOWN UNTIL CABLE JACKET BOTTOMS SECURELY AGAINST SHOULDER IN BODY. SOFT SOLDER CABLE

OTHERWISE SPECIFIED S ARE AFTER PLATING. S & EDGES.005 R. MAX. S THREADS. HINESS 63 V MIL-STD-10. ON CENTERS TO BE CONCENTRIC	SV Microwave, Inc. 2400 Centrepark West Drive, Suite 100 West Palm Beach, FL 33409				
RRS	SEMI-RIGID CABLE TO SMA SOLDER-ON CONNECTOR				
ADK 04/30/07					
RRA 12/06/74	ASSEMBLY INSTRUCTIONS SIZE CAGE CODE DWG. NO. 300-80-118				
: PMG 12/10/74	BIZE B	<b>95077</b>	DWG. NO.	300-80-1	118
ATION: N/A	SC	CALE: 12:1			SHEET 1 OF 1